



**Set grotto bottom piece #6  
Should be level from side to side.**



**Splice rebar from grotto piece  
into rebar schedule from pool  
beam or footing.**



**Extend 2 inch pvc plumbing before  
setting back casting #5. Also run  
sleeves for lighting.**



**Fill back wall and top with concrete mix, 2000 psi  
or better. Top should be level. Requires about  
1/2 yard of concrete mix.**



**Set grotto top piece #7 in fresh concrete or mortar.  
It must be level and shape should match the grotto  
bottom piece. It will drain down when pump is  
off if set properly.**



**Add 2 inches of concrete fill on each side of grotto  
top and mortar in top rocks #8 and #9. Add two  
90's to 2inch return line to discharge onto grotto  
top. Set cap rock #10 to hide pipe.**



**Finish seam between grotto bottom and top.  
Add accent colors to waterfall pieces. Set  
small rocks as desired or to divert waterflow.**